



AVAILABLE COLOURS

- White
- Black
- Silver
- Brown-1
- Champagne
- Brown-3

Button and Cover Colors





1 Gang 1 Way Switch 16A

COLOURS	Model
01 White	SH5101
02 Black	SH5101P-B
03 Silver	SH5101P-S
04 Brown-1	SH5101P-BR1
05 Champagne	SH5101P-CH
06 Brown-3	SH5101P-BR3



1 Gang 2 Way Switch 16A

COLOURS	Model
01 White	SH5102
02 Black	SH5102P-B
03 Silver	SH5102P-S
04 Brown-1	SH5102P-BR1
05 Champagne	SH5102P-CH
06 Brown-3	SH5102P-BR3



1 Gang 3 Way Switch 16A

COLOURS	Model
01 White	SH5103
02 Black	SH5103P-B
03 Silver	SH5103P-S
04 Brown-1	SH5103P-BR1
05 Champagne	SH5103P-CH
06 Brown-3	SH5103P-BR3



1 Gang 1 Way Switch with Led 16A

COLOURS	Model
01 White	SH5104
02 Black	SH5104P-B
03 Silver	SH5104P-S
04 Brown-1	SH5104P-BR1
05 Champagne	SH5104P-CH
06 Brown-3	SH5104P-BR3



1 Gang 1 Way Switch 16A

COLOURS	Model
01 White	SH6101
02 Black	SH6101P-B
03 Silver	SH6101P-S
04 Brown-1	SH6101P-BR1
05 Champagne	SH6101P-CH
06 Brown-3	SH6101P-BR3



1 Gang 2 Way Switch 16A

COLOURS	Model
01 White	SH6102
02 Black	SH6102P-B
03 Silver	SH6102P-S
04 Brown-1	SH6102P-BR1
05 Champagne	SH6102P-CH
06 Brown-3	SH6102P-BR3



1 Gang 3 Way Switch 16A

COLOURS	Model
01 White	SH6103
02 Black	SH6103P-B
03 Silver	SH6103P-S
04 Brown-1	SH6103P-BR1
05 Champagne	SH6103P-CH
06 Brown-3	SH6103P-BR3



1 Gang 1 Way Switch with Led 16A

COLOURS	Model
01 White	SH6104
02 Black	SH6104P-B
03 Silver	SH6104P-S
04 Brown-1	SH6104P-BR1
05 Champagne	SH6104P-CH
06 Brown-3	SH6104P-BR3



Big Size 1 Gang 1 Way Switch 16A

COLOURS	Model
01 White	SH5333
02 Black	SH5333P-B
03 Silver	SH5333P-S
04 Brown-1	SH5333P-BR1
05 Champagne	SH5333P-CH
06 Brown-3	SH5333P-BR3



Big Size 1 Gang 2 Way Switch 16A

COLOURS	Model
01 White	SH5334
02 Black	SH5334P-B
03 Silver	SH5334P-S
04 Brown-1	SH5334P-BR1
05 Champagne	SH5334P-CH
06 Brown-3	SH5334P-BR3



Small Bell Push

COLOURS	Model
01 White	SH5105
02 Black	SH5105P-B
03 Silver	SH5105P-S
04 Brown-1	SH5105P-BR1
05 Champagne	SH5105P-CH
06 Brown-3	SH5105P-BR3



Small Bell Push with LED

COLOURS	Model
01 White	SH5106
02 Black	SH5106P-B
03 Silver	SH5106P-S
04 Brown-1	SH5106P-BR1
05 Champagne	SH5106P-CH
06 Brown-3	SH5106P-BR3



Big Size 1 Gang 1 Way Switch 16A

COLOURS	Model
01 White	SH6333
02 Black	SH6333P-B
03 Silver	SH6333P-S
04 Brown-1	SH6333P-BR1
05 Champagne	SH6333P-CH
06 Brown-3	SH6333P-BR3



Big Size 1 Gang 2 Way Switch 16A

COLOURS	Model
01 White	SH6334
02 Black	SH6334P-B
03 Silver	SH6334P-S
04 Brown-1	SH6334P-BR1
05 Champagne	SH6334P-CH
06 Brown-3	SH6334P-BR3



Small Bell Push

COLOURS	Model
01 White	SH6105
02 Black	SH6105P-B
03 Silver	SH6105P-S
04 Brown-1	SH6105P-BR1
05 Champagne	SH6105P-CH
06 Brown-3	SH6105P-BR3



Small Bell Push with LED

COLOURS	Model
01 White	SH6106
02 Black	SH6106P-B
03 Silver	SH6106P-S
04 Brown-1	SH6106P-BR1
05 Champagne	SH6106P-CH
06 Brown-3	SH6106P-BR3



Big Bell Push

COLOURS	Model
01 White	SH5335
02 Black	SH5335P-B
03 Silver	SH5335P-S
04 Brown-1	SH5335P-BR1
05 Champagne	SH5335P-CH
06 Brown-3	SH5335P-BR3



Big Bell Push with LED

COLOURS	Model
01 White	SH5336
02 Black	SH5336P-B
03 Silver	SH5336P-S
04 Brown-1	SH5336P-BR1
05 Champagne	SH5336P-CH
06 Brown-3	SH5336P-BR3



2 Gang 1 Way Switch

COLOURS	Model
01 White	SH5107
02 Black	SH5107P-B
03 Silver	SH5107P-S
04 Brown-1	SH5107P-BR1
05 Champagne	SH5107P-CH
06 Brown-3	SH5107P-BR3



2 Gang 2 Way Switch

COLOURS	Model
01 White	SH5108
02 Black	SH5108P-B
03 Silver	SH5108P-S
04 Brown-1	SH5108P-BR1
05 Champagne	SH5108P-CH
06 Brown-3	SH5108P-BR3



Big Bell Push

COLOURS	Model
01 White	SH6335
02 Black	SH6335P-B
03 Silver	SH6335P-S
04 Brown-1	SH6335P-BR1
05 Champagne	SH6335P-CH
06 Brown-3	SH6335P-BR3



Big Bell Push with LED

COLOURS	Model
01 White	SH6336
02 Black	SH6336P-B
03 Silver	SH6336P-S
04 Brown-1	SH6336P-BR1
05 Champagne	SH6336P-CH
06 Brown-3	SH6336P-BR3



2 Gang 1 Way Switch

COLOURS	Model
01 White	SH6107
02 Black	SH6107P-B
03 Silver	SH6107P-S
04 Brown-1	SH6107P-BR1
05 Champagne	SH6107P-CH
06 Brown-3	SH6107P-BR3



2 Gang 2 Way Switch

COLOURS	Model
01 White	SH6108
02 Black	SH6108P-B
03 Silver	SH6108P-S
04 Brown-1	SH6108P-BR1
05 Champagne	SH6108P-CH
06 Brown-3	SH6108P-BR3



2 Pin Socket(Middle With Round)

COLOURS	Model
01 White	SH5112
02 Black	SH5112P-B
03 Silver	SH5112P-S
04 Brown-1	SH5112P-BR1
05 Champagne	SH5112P-CH
06 Brown-3	SH5112P-BR3



3 Round Socket

COLOURS	Model
01 White	SH5113
02 Black	SH5113P-B
03 Silver	SH5113P-S
04 Brown-1	SH5113P-BR1
05 Champagne	SH5113P-CH
06 Brown-3	SH5113P-BR3



2 Round Socket

COLOURS	Model
01 White	SH5114
02 Black	SH5114P-B
03 Silver	SH5114P-S
04 Brown-1	SH5114P-BR1
05 Champagne	SH5114P-CH
06 Brown-3	SH5114P-BR3



2 Pin Socket

COLOURS	Model
01 White	SH5115
02 Black	SH5115P-B
03 Silver	SH5115P-S
04 Brown-1	SH5115P-BR1
05 Champagne	SH5115P-CH
06 Brown-3	SH5115P-BR3



700W Fan Controller

COLOURS	Model
01 White	SH5228
02 Black	SH5228P-B
03 Silver	SH5228P-S
04 Brown-1	SH5228P-BR1
05 Champagne	SH5228P-CH
06 Brown-3	SH5228P-BR3



100W Sensitive Controller Time Delay Switch(3minutes)

COLOURS	Model
01 White	SH5230
02 Black	SH5230P-B
03 Silver	SH5230P-S
04 Brown-1	SH5230P-BR1
05 Champagne	SH5230P-CH
06 Brown-3	SH5230P-BR3



Big Bath Room Door Bell

COLOURS	Model
01 White	SH5231
02 Black	SH5231P-B
03 Silver	SH5231P-S
04 Brown-1	SH5231P-BR1
05 Champagne	SH5231P-CH
06 Brown-3	SH5231P-BR3



Small Bath Room Door Bell

COLOURS	Model
01 White	SH5121
02 Black	SH5121P-B
03 Silver	SH5121P-S
04 Brown-1	SH5121P-BR1
05 Champagne	SH5121P-CH
06 Brown-3	SH5121P-BR3



2 Pin Socket(Middle With Round)

COLOURS	Model
01 White	SH5116
02 Black	SH5116P-B
03 Silver	SH5116P-S
04 Brown-1	SH5116P-BR1
05 Champagne	SH5116P-CH
06 Brown-3	SH5116P-BR3



German Socket

COLOURS	Model
01 White	SH5225
02 Black	SH5225P-B
03 Silver	SH5225P-S
04 Brown-1	SH5225P-BR1
05 Champagne	SH5225P-CH
06 Brown-3	SH5225P-BR3



Multifunction Socket

COLOURS	Model
01 White	SH5226
02 Black	SH5226P-B
03 Silver	SH5226P-S
04 Brown-1	SH5226P-BR1
05 Champagne	SH5226P-CH
06 Brown-3	SH5226P-BR3



(American) TEL Socket

COLOURS	Model
01 White	SH5117
02 Black	SH5117P-B
03 Silver	SH5117P-S
04 Brown-1	SH5117P-BR1
05 Champagne	SH5117P-CH
06 Brown-3	SH5117P-BR3



12 LED AC220V

COLOURS	Model
01 White	SH5122
02 Black	SH5122P-B
03 Silver	SH5122P-S
04 Brown-1	SH5122P-BR1
05 Champagne	SH5122P-CH
06 Brown-3	SH5122P-BR3



24 LED AC220V

COLOURS	Model
01 White	SH5232
02 Black	SH5232P-B
03 Silver	SH5232P-S
04 Brown-1	SH5232P-BR1
05 Champagne	SH5232P-CH
06 Brown-3	SH5232P-BR3



Big Switch Fill Part

COLOURS	Model
01 White	SH5110
02 Black	SH5110P-B
03 Silver	SH5110P-S
04 Brown-1	SH5110P-BR1
05 Champagne	SH5110P-CH
06 Brown-3	SH5110P-BR3



Small Switch Fill Part

COLOURS	Model
01 White	SH5111
02 Black	SH5111P-B
03 Silver	SH5111P-S
04 Brown-1	SH5111P-BR1
05 Champagne	SH5111P-CH
06 Brown-3	SH5111P-BR3



8 Core Data Socket

COLOURS	Model
01 White	SH5118
02 Black	SH5118P-B
03 Silver	SH5118P-S
04 Brown-1	SH5118P-BR1
05 Champagne	SH5118P-CH
06 Brown-3	SH5118P-BR3



Satellite Socket

COLOURS	Model
01 White	SH5120
02 Black	SH5120P-B
03 Silver	SH5120P-S
04 Brown-1	SH5120P-BR1
05 Champagne	SH5120P-CH
06 Brown-3	SH5120P-BR3



700W Dimmer

COLOURS	Model
01 White	SH5227
02 Black	SH5227P-B
03 Silver	SH5227P-S
04 Brown-1	SH5227P-BR1
05 Champagne	SH5227P-CH
06 Brown-3	SH5227P-BR3



TV Socket

COLOURS	Model
01 White	SH5119
02 Black	SH5119P-B
03 Silver	SH5119P-S
04 Brown-1	SH5119P-BR1
05 Champagne	SH5119P-CH
06 Brown-3	SH5119P-BR3



USB Socket

COLOURS	Model
01 White	SH5123
02 Black	SH5123P-B
03 Silver	SH5123P-S
04 Brown-1	SH5123P-BR1
05 Champagne	SH5123P-CH
06 Brown-3	SH5123P-BR3



Window Switch

COLOURS	Model
01 White	SH5109
02 Black	SH5109P-B
03 Silver	SH5109P-S
04 Brown-1	SH5109P-BR1
05 Champagne	SH5109P-CH
06 Brown-3	SH5109P-BR3



Video

COLOURS	Model
01 White	SH5124
02 Black	SH5124P-B
03 Silver	SH5124P-S
04 Brown-1	SH5124P-BR1
05 Champagne	SH5124P-CH
06 Brown-3	SH5124P-BR3



SH5337 5 LED White



SH5338 5 LED Red



(Aluminum)
(Stainless Steel)
(Champagne with Black)



45AM LED LIGHT

COLOURS	Model
01 White	SH6339
02 Black	SH6339P-B
03 Silver	SH6339P-S
04 Brown-1	SH6339P-BR1
05 Champagne	SH6339P-CH
06 Brown-3	SH6339P-BR3



20AM LED LIGHT

COLOURS	Model
01 White	SH6340
02 Black	SH6340P-B
03 Silver	SH6340P-S
04 Brown-1	SH6340P-BR1
05 Champagne	SH6340P-CH
06 Brown-3	SH6340P-BR3



32AM LED LIGHT

COLOURS	Model
01 White	SH6339-32
02 Black	SH6339P-B-32
03 Silver	SH6339P-S-32
04 Brown-1	SH6339P-BR1-32
05 Champagne	SH6339P-CH-32
06 Brown-3	SH6339P-BR3-32



45AM

COLOURS	Model
01 White	SH5339
02 Black	SH5339P-B
03 Silver	SH5339P-S
04 Brown-1	SH5339P-BR1
05 Champagne	SH5339P-CH
06 Brown-3	SH5339P-BR3



20AM

COLOURS	Model
01 White	SH5340
02 Black	SH5340P-B
03 Silver	SH5340P-S
04 Brown-1	SH5340P-BR1
05 Champagne	SH5340P-CH
06 Brown-3	SH5340P-BR3



32AM

COLOURS	Model
01 White	SH5339-32
02 Black	SH5339P-B-32
03 Silver	SH5339P-S-32
04 Brown-1	SH5339P-BR1-32
05 Champagne	SH5339P-CH-32
06 Brown-3	SH5339P-BR3-32

1 Gang 1 Way Switch 16A



SH6101AL-C3 SH6101AL SH6101B6-C3 SH6101B6-C2 SH6101HK-CH SH6101HK-C3



SH6101CH-C3 SH6101CH-C2 SH6101CH-B SH6101ST-C3 SH6101SS

1 Gang 2 Way Switch 16A



SH6102AL-C3 SH6102AL SH6102B6-C3 SH6102B6-C2 SH6102HK-CH SH6102HK-C3



SH6102CH-C3 SH6102CH-C2 SH6102CH-B SH6102ST-C3 SH6102SS

(Aluminum)
(Stainless Steel)
(Champagne with Black)

1 Gang 1 Way Switch 16A



2 Gang 1 Way Switch 16A



1 Gang 2 Way Switch 16A



2 Gang 2 Way Switch 16A



(Aluminum)
(Stainless Steel)
(Champagne with Black)

1 Gang 3 Way Switch 16A



Small Bell Push



Window Switch



Big Bell Push



Bracket (White)



SH5342



SH5443



SH5645

Bracket (painting)



SH5342B BLACK



SH5342-S SILVER



SH5342-P7 CHAMPAGNE



SH5342-BR1 BROWN 1



SH5342-BR3 BROWN 3

Bracket (Stainless Steel)



SH1052-B-B-RG



SH1052-B-B-G



SH1052-B-B-C



SH1052-B-B-GG



SH1052-B-B-HK



SH1052-HK-C




SH1052-HK-CH


Bracket (Stainless Steel)



SH1052ST-C3




SH5341SS



SH1052B6-C3



SH1052B6-C2




SH1052AL-C3



SH1052CH-C3



SH1052CH-C2



SH1052HK-C3

Switch Cover Brushed (painting)



SH1037-P7/B CHAMPAGNE



SH1037-BR1/B BROWN 1




SH1037-P6/B DARK COPPER



SH1037-P4/B DARK GREY



SH1037-P2/B DARK BLUE



SH1037-B/B BLACK



SH1037-P5/B BROWN 2



SH1037-S/B SILVER



SH1037-R/B RED



SH1037-BR3/B BROWN3

Switch Cover Flower (painting)



SH1037-P7/F CHAMPAGNE



SH1037-BR1/F BROWN 1




SH1037-P6/F DARK COPPER



SH1037-P4/F DARK GREY



SH1037-P2/F DARK BLUE




SH1037-B/F BLACK



SH1037-P5/F BROWN 2



SH1037-S/F SILVER



SH1037-R/F RED



SH1037-BR3/F BROWN3

Switch Cover (painting)



SH5341-P7 CHAMPAGNE



SH5341-BR1 BROWN 1



SH5341-P6 DARK COPPER



SH5341-P4 DARK GREY



SH5341-P2 DARK BLUE



SH5341B BLACK



SH5341-P5 BROWN 2



SH5341S SILVER



SH5341R RED



SH5351BR-3 BROWN3

Injection Cover



SH5341-IN1




SH5341-IN2



SH5341-IN3



SH5341-IN4



SH5341-IN5



SH5341-IN6



SH5341-IN7



SH5341-IN8



SH5341-IN9



SH5341-IN10



SH5341-IN11



SH5341-IN12



SH5341-IN13



SH5341-IN14



SH5341-IN15



SH5341-IN16




SH5341-IN17



SH5341-IN18



SH5341-IN19



SH5341-IN20



SH5341-IN21



SH5341-IN22



SH5341-IN23



SH5341-IN24

Formica Cover



Chrome Cover

Chrome Bracket

Line Cover With Gold Frame

Line Cover With Chrome Frame



Glass with Chrome Bracket



SH5340-C WHITE




SH5341-C BLACK



SH5342-C DARK GREY



SH5343-C CHAMPAGNE




SH5344-C DARK CHAMPAGNE



SH5345-C LIGHT BROWN



SH5346-C SILVER GREY



SH5347-C EGGPLANT



SH5348-C PINK



SH5349-C DARK PINK



SH5350-C ORANGE



SH5351-C DARK ORANGE



SH5352-C RED



SH5353-C CHOCOLATE



SH5354-C PURPLE



SH5355-C DARK RED



SH5356-C DARK COFFEE

Glass with Red Gold Bracket



SH5340-RG WHITE



SH5341-RG BLACK



SH5342-RG DARK GREY



SH5343-RG CHAMPAGNE



SH5344-RG DARK CHAMPAGNE



SH5345-RG LIGHT BROWN




SH5346-RG SILVER GREY



SH5347-RG EGGPLANT



SH5348-RG PINK



SH5349-RG DARK PINK



SH5350-RG ORANGE



SH5351-RG DARK ORANGE



SH5352-RG RED



SH5353-RG CHOCOLATE



SH5354-RG PURPLE



SH5355-RG DARK RED



SH5356-RG DARK COFFEE

Glass with Gold Bracket



Glass with HK Mirror Bracket

